left

front

right (partition)

back

superwool

partition (400x315x24), on the back
of it a ledge (98x24x12)

joining block 144x98x62

buffer to trapdoor
(146x62x19)

notch 28x15

notch at the top 63x15x20

notch 35x15

joining block seen from above (144x98x62)

62

35

Buffer of trapdoor seen from above.
You glue it with cement glue.

08. Installing the core, joining block and partition, buffer to trapdoor